


Quickstart Guide for Zenput Sensors and Gateway


Follow the steps below to set up your Zenput gateway and sensors in your location to get started with Zenput Temp Monitoring.



STEP 1

Open the Zenput app and unbox your devices


- Navigate to your store location or the location where you will install the device
- Tap the Sensors tab at the top of the screen



STEP 2

Power on and register the **gateway** in Zenput

- Select "Set Up Gateway" in the Sensors tab of the Zenput mobile app and follow the instructions in the setup wizard
- Provide a nickname for the gateway, such as "Back Office Gateway" or use your store name or number
- Use the barcode scanner in the app, or manually enter the gateway ID number and SC code in Zenput



STEP 3

Register the **sensor** in Zenput

NOTE: Complete steps 3 and 4 for each sensor before registering any additional sensors

- Before powering on the sensor, in the Zenput app, select "Add Sensor"
- From the drop-down menu, select a placement for where the sensor will be located, such as "Refrigerator"
- Provide a nickname for the sensor, such as "Front Fridge". This name will make it easy to identify the temperatures for this specific device in Zenput
- Use the barcode scanner in the app, or manually enter the sensor ID number and SC code in Zenput



Success!

STEP 4

Power on and place the sensor

- Power on the sensor by inserting the batteries
- Place the sensor in the desired location
- From the main Sensors tab, the new sensor will appear with "initializing" as its status for about 45 minutes, and will begin populating data within 15 minutes